

## FM Broadcast Channel Frequencies (MHz)

Channel	Frequency	Channel	Frequency	Channel	Frequency
1	88.1	35	94.9	69	101.7
2	88.3	36	95.1	70	101.9
3	88.5	37	95.3	71	102.1
4	88.7	38	95.5	72	102.3
5	88.9	39	95.7	73	102.5
6	89.1	40	95.9	74	102.7
7	89.3	41	96.1	75	102.9
8	89.5	42	96.3	76	103.1
9	89.7	43	96.5	77	103.3
10	89.9	44	96.7	78	103.5
11	90.1	45	96.9	79	103.7
12	90.3	46	97.1	80	103.9
13	90.5	47	97.3	81	104.1
14	90.7	48	97.5	82	104.3
15	90.9	49	97.7	83	104.5
16	91.1	50	97.9	84	104.7
17	91.3	51	98.1	85	104.9
18	91.5	52	98.3	86	105.1
19	91.7	53	98.5	87	105.3
20	91.9	54	98.7	88	105.5
21	92.1	55	98.9	89	105.7
22	92.3	56	99.1	90	105.9
23	92.5	57	99.3	91	106.1
24	92.7	58	99.5	92	106.3
25	92.9	59	99.7	93	106.5
26	93.1	60	99.9	94	106.7
27	93.3	61	100.1	95	106.9
28	93.5	62	100.3	96	107.1
29	93.7	63	100.5	97	107.3
30	93.9	64	100.7	98	107.5
31	94.1	65	100.9	99	107.7
32	94.3	66	101.1	100	107.9
33	94.5	67	101.3		
34	94.7	68	101.5		